

Operation guide for Pull Up screen

Thank you for buying a KINGPIN screen! Read this operation guide to get the most out of your screen.

INSTALLATION

The screen doesn't need installation, it can be used at once. Just place it on the floor and use.

USE

When using the screen, pull out the two supporting legs under the cassette to stabilize the screen, open up the cassette and pull up the screen to desired height by using the handle. The height can easily be adjusted by pressing or pulling the handle.

To keep your screen in good condition, always wind the screen back into the cassette after use. Do not expose the screen to direct sunlight or high temperatures.

Initially, there might be small waves on the surface of the screen. These are due to changes in air pressure during transport, and normally most of them disappear within a few days. However, screen fabric rolled up on an axle is seldom entirely free from waves.

CARE

Use a moist cotton cloth to clean the screen surface. Do not use strong chemicals.

SERVICE AND WARRANTY

The warranty period for this product is 2 years after purchase, Keep the package box for possible future service. The warranty is applicable only to manufacturing defects. Complaints should be made directly to distributor. The warranty is not valid if the defect is caused by the consumer, or if the product is modified in any way.

In case of transportation damage, please contact the delivery service as soon as possible. Kingpin Screens is not responsible for transportation damage.